
BATTERY HOLDER FOR RTC, DS1307
BATTERY IS INCLUDED
LCD R/W
ENABLE
I2C
INTERFACE
4 SERVO OUTPUTS
TRIMMER POT
VGA CAMERA
INTERFACE
RS232
SIGNALS
EXT. LCD
CONNECTOR
LCD
BACK LIGHT
ENABLE
2 CH DAC
OUTPUTS
EXTERNAL 5V
FOR SERVOS
SPI
INTERFACE
RF XMIT
MODULE
TEMP.
SENSOR
PHOTO
TRANSISTOR
2 ANALOG
OR DIGITAL
ALARM
TRIGGERS
3.3V
REG.
SD/MMC
MEMORY
CARD
HOLDER
FORM C
RELAY
OUTPUT
4X4
KEYPAD
X-Y-Z
ACCELEROMETER
OR DISTANCE
SENSOR GP2D12
INTERFACE
SCI0
SCI1
CAN 0
RS485
EXT.9V
INPUT
9V DC 500mA
2.1MM JACK
CENTER POSITIVE
SPEAKER
IR XMIT
2 H-BRIDGE
OUTPUTS
MOTOR FEEDBACK OR
ROTARY ENCODER
INTERFACE
RESET SWITCH
IR RECV
RF RECV
OPTO COUPLER
OUTPUT
LOGIC
PROBE
ABORT
SWITCH
MODE
SELECTOR
(C)2002-2008
EVBPLUS.COM
DRAGON12-P REV.F