
CSE 4201

Computer Architecture

Prof. Mokhtar Aboelaze

Parts of these slides are taken from
Notes by Prof. David Patterson at UCB

Fall 07

CSE4201

Outline

- MIPS and instruction set
- Simple pipeline in MIPS
- Structural and data hazards
- Forwarding
- Branching
- Exception and interrupts
- Multicycle operations

Fall 07

CSE4201

MIPS Instruction set

- 32-bit fixed format instruction (3 formats)
- 32 32-bit GPR (R0 contains zero, DP take pair)
- 3-address, reg-reg arithmetic instruction
- Single address mode for load/store:
base + displacement
 - no indirection
- Simple branch conditions
- Delayed branch

Fall 07

CSE4201

Instruction Set

- Instruction Set Architecture
 - Defines set of operations, instruction format, hardware supported data types, named storage, addressing modes, sequencing
- Meaning of each instruction is described by RTL on *architected registers* and memory
- Given technology constraints assemble adequate datapath
 - Architected storage mapped to actual storage
 - Function units to do all the required operations
 - Possible additional storage (eg. MAR, MBR, ...)
 - Interconnect to move information among regs and FUs
- Map each instruction to sequence of RTLs
- Collate sequences into symbolic controller state transition diagram (STD)
- Lower symbolic STD to control points
- Implement controller

Fall 07

CSE4201

MIPS Instruction Set





FIGURE 3.1 The implementation of the DLX datapath allows every instruction to be executed in four or five clock cycles.

Fall 07


CSE4201

MIPS Instruction Set


Register-Register



Register-Immediate



Branch




Jump / Call



Fall 07

CSE4201


MIPS 5-Stage Pipeline



Fall 07

CSE4201


5-stage Pipeline



Fall 07


CSE4201

MIPS 5-Stage Pipeline



5 Steps of MIPS Datapath


Figure A.3, Page A-9



- **Data stationary control**
 - local decode for each instruction phase / pipeline stage

Visualizing Pipelining

Figure A.2, Page A-8



Pipelining is not quite that easy!


- Limits to pipelining: **Hazards** prevent next instruction from executing during its designated clock cycle
 - **Structural hazards**: HW cannot support this combination of instructions (single person to fold and put clothes away)
 - **Data hazards**: Instruction depends on result of prior instruction still in the pipeline (missing sock)
 - **Control hazards**: Caused by delay between the fetching of instructions and decisions about changes in control flow (branches and jumps).

Fall 07


CSE4201

One Memory Port/Structural Hazards

Figure A.4, Page A-14



One Memory Port/Structural Hazards



Speed Up Equation for Pipelining

$$CPI_{\text{pipelined}} = \text{Ideal CPI} + \text{Average Stall cycles per Inst}$$

$$\text{Speedup} = \frac{\text{Ideal CPI} \times \text{Pipeline depth}}{\text{Ideal CPI} + \text{Pipeline stall CPI}} \times \frac{\text{Cycle Time}_{\text{unpipelined}}}{\text{Cycle Time}_{\text{pipelined}}}$$

For simple RISC pipeline, CPI = 1:

$$\text{Speedup} = \frac{\text{Pipeline depth}}{1 + \text{Pipeline stall CPI}} \times \frac{\text{Cycle Time}_{\text{unpipelined}}}{\text{Cycle Time}_{\text{pipelined}}}$$

Fall 07

CSE4201

Example: Dual-port vs. Single-port

- Machine A: Dual ported memory (“Harvard Architecture”)
- Machine B: Single ported memory, but its pipelined implementation has a 1.05 times faster clock rate
- Ideal CPI = 1 for both
- Loads are 40% of instructions executed

$$\begin{aligned} \text{SpeedUp}_A &= \text{Pipeline Depth} / (1 + 0) \times (\text{clock}_{\text{unpipe}} / \text{clock}_{\text{pipe}}) \\ &= \text{Pipeline Depth} \end{aligned}$$

$$\begin{aligned} \text{SpeedUp}_B &= \text{Pipeline Depth} / (1 + 0.4 \times 1) \times (\text{clock}_{\text{unpipe}} / (\text{clock}_{\text{unpipe}} / 1.05)) \\ &= (\text{Pipeline Depth} / 1.4) \times 1.05 \\ &= 0.75 \times \text{Pipeline Depth} \end{aligned}$$

$$\text{SpeedUp}_A / \text{SpeedUp}_B = \text{Pipeline Depth} / (0.75 \times \text{Pipeline Depth}) = 1.33$$


- Machine A is 1.33 times faster

Fall 07

CSE4201

Data Hazard on R1

Figure A.6, Page A-17



Three Generic Data Hazards

- Read After Write (RAW)

Instr_j tries to read operand before Instr_i writes it

I: add r1, r2, r3
 J: sub r4, r1, r3

- Caused by a “Dependence” (in compiler nomenclature). This hazard results from an actual need for communication.

Fall 07

CSE4201

Three Generic Data Hazards

- Write After Read (WAR)

Instr_j writes operand before Instr_i reads it

```

    I: sub r4,r1,r3
    J: add r1,r2,r3
    K: mul r6,r1,r7
  
```

- Called an “anti-dependence” by compiler writers. This results from reuse of the name “r1”.
- Can’t happen in MIPS 5 stage pipeline because:
 - All instructions take 5 stages, and
 - Reads are always in stage 2, and
 - Writes are always in stage 5

Fall 07

CSE4201

Three Generic Data Hazards

- Write After Write (WAW)

Instr_j writes operand before Instr_i writes it.

```


    I: sub r1,r4,r3
    J: add r1,r2,r3
    K: mul r6,r1,r7
  
```

- Called an “output dependence” by compiler writers. This also results from the reuse of name “r1”.
- Can’t happen in MIPS 5 stage pipeline because:
 - All instructions take 5 stages, and
 - Writes are always in stage 5
- Will see WAR and WAW in more complicated pipes

Fall 07

CSE4201


Forwarding to Avoid Data Hazard



Fall 07

CSE4201

HW Change for Forwarding




What circuit detects and resolves this hazard?

Fall 07

CSE4201


Forwarding to Avoid LW-SW Data Hazard



Fall 07

CSE4201


Data Hazard Even with Forwarding



Fall 07

CSE4201

Data Hazard Even with Forwarding



Fall

How is this detected?

CSE4201

Software Scheduling to Avoid Load Hazards

Try producing fast code for

$a = b + c;$

$d = e - f;$

assuming a, b, c, d, e, and f in memory.

Slow code:

```
LW    Rb,b
LW    Rc,c
ADD   Ra,Rb,Rc
SW    a,Ra
LW    Re,e
LW    Rf,f
SUB   Rd,Re,Rf
SW    d,Rd
```

Fast code:

```
LW    Rb,b
LW    Rc,c
LW    Re,e
ADD   Ra,Rb,Rc
LW    Rf,f
SW    a,Ra
SUB   Rd,Re,Rf
SW    d,Rd
```


Fall 07

Compiler optimizes for performance. Hardware checks for safety.

CSE4201

Control Hazard on Branches

Three Stage Stall



What do you do with the 3 instructions in between?

How do you do it?

Where is the "commit"?

Fall 07

CSE4201

Branch Stall Impact


- If CPI = 1, 30% branch,
Stall 3 cycles => new CPI = 1.9!
- Two part solution:
 - Determine branch taken or not sooner, AND
 - Compute taken branch address earlier
- MIPS branch tests if register = 0 or $\neq 0$
- MIPS Solution:
 - Move Zero test to ID/RF stage
 - Adder to calculate new PC in ID/RF stage
 - 1 clock cycle penalty for branch versus 3

Fall 07

CSE4201

Pipelined MIPS Datapath

Figure A.24, page A-38



• Interplay of instruction set design and cycle time.

Fall 07

CSE4201

Four Branch Hazard Alternatives

#1: Stall until branch direction is clear

#2: Predict Branch Not Taken

- Execute successor instructions in sequence
- “Squash” instructions in pipeline if branch actually taken
- Advantage of late pipeline state update
- 47% MIPS branches not taken on average
- PC+4 already calculated, so use it to get next instruction

#3: Predict Branch Taken

- 53% MIPS branches taken on average
- But haven't calculated branch target address in MIPS
 - MIPS still incurs 1 cycle branch penalty
 - Other machines: branch target known before outcome


Fall 07

CSE4201

Four Branch Hazard Alternatives

#4: Delayed Branch

- Define branch to take place **AFTER** a following instruction




- 1 slot delay allows proper decision and branch target address in 5 stage pipeline
- MIPS uses this

Fall 07


CSE4201

Scheduling Branch Delay Slots


A. From before branch




becomes




B. From branch target




becomes



C. From fall through



becomes



- A is the best choice, fills delay slot & reduces instruction count (IC)
- In B, the `sub` instruction may need to be copied, increasing IC
- In B and C, must be okay to execute `sub` when branch fails

Fall 07

CSE4201

Delayed Branch

- Compiler effectiveness for single branch delay slot:
 - Fills about 60% of branch delay slots
 - About 80% of instructions executed in branch delay slots useful in computation
 - About 50% (60% x 80%) of slots usefully filled
- Delayed Branch downside: As processor go to deeper pipelines and multiple issue, the branch delay grows and need more than one delay slot
 - Delayed branching has lost popularity compared to more expensive but more flexible dynamic approaches
 - Growth in available transistors has made dynamic approaches relatively cheaper

Fall 07

CSE4201

Evaluating Branch Alternatives

$$\text{Pipeline speedup} = \frac{\text{Pipeline depth}}{1 + \text{Branch frequency} \times \text{Branch penalty}}$$

Assume 4% unconditional branch, 6% conditional branch- untaken, 10% conditional branch-taken

Scheduling Branch CPI speedup v. speedup v. scheme penalty unpipelined stall

Stall pipeline	3	1.60	3.1	1.0
Predict taken	1	1.20	4.2	1.33
Predict not taken	1	1.14	4.4	1.40

Delayed branch	0.5	1.10	4.5	1.45
----------------	-----	------	-----	------

Fall 07

CSE4201

Problems with Pipelining

- **Exception:** An unusual event happens to an instruction during its execution
 - Examples: divide by zero, undefined opcode
- **Interrupt:** Hardware signal to switch the processor to a new instruction stream
 - Example: a sound card interrupts when it needs more audio output samples (an audio “click” happens if it is left waiting)
- **Problem:** It must appear that the exception or interrupt must appear between 2 instructions (I_i and I_{i+1})
 - The effect of all instructions up to and including I_i is totally complete
 - No effect of any instruction after I_i can take place
- The interrupt (exception) handler either aborts program or restarts at instruction I_{i+1}

Fall 07

CSE4201

And In Conclusion: Control and Pipelining

- Quantify and summarize performance
 - Ratios, Geometric Mean, Multiplicative Standard Deviation
- F&P: Benchmarks age, disks fail, 1 point fail danger
- Control VIA **State Machines** and **Microprogramming**
- Just overlap tasks; easy if tasks are independent
- Speed Up \leq Pipeline Depth; if ideal CPI is 1, then:

$$\text{Speedup} = \frac{\text{Pipeline depth}}{1 + \text{Pipeline stall CPI}} \times \frac{\text{Cycle Time}_{\text{unpipelined}}}{\text{Cycle Time}_{\text{pipelined}}}$$


- Hazards limit performance on computers:
 - Structural: need more HW resources
 - Data (RAW, WAR, WAW): need forwarding, compiler scheduling
 - Control: delayed branch, prediction
- Exceptions, Interrupts add complexity

Fall 07

CSE4201

Multicycle operations

More than one function unit, each require a variable number of cycles.



Fall 07

CSE4201

Multi cycles operations

- Assuming the following


Function	Unit latency	initiation period
Integer ALU	0	1
Data Memory	1	1
FP add	3	1
FP Multiply	6	1
FP Divide	24	24

Notice that FP add and multiply are pipelined (4 and 7 stages pipeline respectively).

Latency is the number of cycles between an instruction that produces a result and another one that uses the result.

Fall 07

CSE4201



Fall 07

CSE4201

Multicycle operations

MULTD	IF	ID	M1	M2	M3	M4	M5	M6	M7	MEM	WB
ADDD		IF	ID	A1	A2	A3	A4	MEM	WB		
LD		IF	ID	EX	MEM	WB					
SD			IF	ID	EX	MEM	WB				

Stages in red indicates when data are needed, in blue indicates when data are produced

Need to introduce more pipeline registers A1/A2, ..

Fall 07

CSE4201

Hazards and Forwarding

- Because the divide unit is not pipelined, structural hazards may arise
- Because of different running times. We may need to do more than one register write in a single cycle
- WAW hazard is now possible, WAR is not since they all read in one stage
- Instructions can complete in different order, more complicated exception handling
- Because of the longer latency, more RAW

Fall 07 hazard

CSE4201

Hazards and Forwarding

Instruction	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
LD F4,0(R2)	IF	ID	EX	MEM	WB										
MUL F0,F4,F6		IF	ID	S	M1	M2	M3	M4	M5	M6	M7	MEM	WB		
ADDD F2,F0,F8			IF	ID	S	S	S	S	S	S	S	A1	A2	A3	A4
SD F2,0(R2)				IF	ID	S	S	S	S	S	S	S	S	S	MEM

Substantially longer stall and forwarding

Fall 07

CSE4201

Hazard and Forwarding

Instruction	1	2	3	4	5	6	7	8	9	10	11
MULTD F0,F4,F6	IF	ID	M1	M2	M3	M4	M5	M6	M7	MEM	WB
...											
...											
ADDD F2,F4,F6				IF	ID	A1	A2	A3	A4	MEM	WB
...											
...											
LD F8,0(R2)							IF	ID	EX	MEM	WB

Three different instruction writing in the same cycle, IF LD is issued one cycle earlier, with destination of F2, that will lead to WAW hazard

Fall 07

CSE4201

Hazards and Forwarding

- One way to deal with multiple writes is to have multiple write ports, but it may be rarely used.
- Another way is to detect the structural hazard by using an interlock
 1. We can track the use of the write port before it is issued (ID stage) and stall
 2. Or, we can detect this hazard at entering the MEM stage, it is easier to detect, and we can choose which instruction to proceed (the one with the longest latency?)

Fall 07

CSE4201

Maintaining Precise Exception

DIVF F0, F2, F4
ADDF F10, F10, F8
SUBF F12, F12, F14

- This is known as out of order completion
- What if SUBF causes an Exception after ADDF is completed but before DIVF is, or if DIVF caused an exception after both ADDF and SUBF completed, there is no way to maintain a precise exception since ADDF destroys one of its operands

Fall 07

CSE4201

Maintaining Precise Exception (sol 1)

- Early solution is to ignore the problem
- More recent ones, are to introduce two modes of operations, fast but with imprecise exception, and slow with precise exception.
- DEC Alpha 2104, Power1 and Power-2, MIPS R8000

Fall 07

CSE4201

Maintaining Precise Exception (sol 2)

- Buffer the results of an operation until all the operations before it are completed.
- Costly, especially with long pipes.
- One variation is called history file, old values are stored in the history file and can be restored in case of exception
- Or, we can use future file, where new values are stored until all proceeding instructions are completed.

Fall 07

CSE4201

Maintaining Precise Exception (sol 3)

- Allow the exception to become imprecise, but we have to keep enough information so that the exception handling routine can recover.
- These information are usually the PC addresses of the instructions that were in the pipe during the exception, who finished, and who not.

Fall 07

CSE4201

Maintaining Precise Exception (sol 4)

- A hybrid technique, Allow the instructions to be issued only if we are certain that all the instructions before the issuing instruction will complete without causing an exception
- That guarantees that no instruction after the interrupting one will be completed, and all instructions before it will complete.
- Must check for exception early in the EX stage.

Fall 07

CSE4201


MIPS4000

- 8 Stage Pipeline:
 - IF—first half of fetching of instruction; PC selection happens here as well as initiation of instruction cache access.
 - IS—second half of access to instruction cache.
 - RF—instruction decode and register fetch, hazard checking and also instruction cache hit detection.
 - EX—execution, which includes effective address calculation, ALU operation, and branch target computation and condition evaluation.
 - DF—data fetch, first half of access to data cache.
 - DS—second half of access to data cache.
 - TC—tag check, determine whether the data cache access hit.
 - WB—write back for loads and register-register operations.
- 8 Stages: What is impact on Load delay? Branch delay? Why?

Fall 07

CSE4201

MIPS4000



Fall 07

CSE4201

MIPS4000 FP Pipeline

- FP Adder, FP Multiplier, FP Divider
- Last step of FP Multiplier/Divider uses FP Adder HW
- 8 kinds of stages in FP units:

Stage	Functional unit	Description
A	FP adder	Mantissa ADD stage
D	FP divider	Divide pipeline stage
E	FP multiplier	Exception test stage
M	FP multiplier	First stage of multiplier
N	FP multiplier	Second stage of multiplier
R	FP adder	Rounding stage
S	FP adder	Operand shift stage
U		Unpack FP numbers

Fall 07

CSE4201

MIPS4000 F P Pipeline

<i>FP Instr</i>	<i>Pipeline stages</i>
Add, Subtract	U,S+A,A+R,R+S
Multiply	U,E+M,M,M,M,N,N+A,R
Divide	U,A,R,D ²⁸ ,D+A,D+R, D+R, D+A, D+R, A, R
Square root	U,E,(A+R) ¹⁰⁸ ,A,R
Negate	U,S
Absolute value	U,S
FP compare	U,A,R

<i>OP</i>	<i>Latency</i>	<i>Initiation interval</i>
ADD,SUB	4	3
MUL	8	4
DIV	36	35
SQRT	112	111
NEG,ABS	2	1
COMP	3	2

Fall 07

CSE4201

EXAMPLE

		0	1	2	3	4	5	6	7	8	9	10
• MUL	ISSUE	U	M	M	M	M	N	N,A	R			
• ADD	Issue		U	S,A	A,R	R,S						
• ADD	Issue			U	S,A	A,R	R,S					
• ADD	Stall				U	S,A	A,R	R,S				
• ADD	Stall					U	S,A	A,R	R,S			
• ADD	Issue						U	S,A	A,R	R,S		
• ADD	Issue							U	S,A	A,R	R,S	
• ADD	Issue								U	S,A	A,R	R,S

The interaction between a multiply issued at time 0, and add issued between 1 and 7, in all except 2 we can proceed without stalls, in these two we have to stall

Fall 07

CSE4201